

Life Smart
Simply Brilliant

Smart Fan Coil Thermostat

Setting up your LifeSmart Smart Fan Coil Thermostat
User Guide Version 1.0

PRODUCT INTRODUCTION

Combine the LifeSmart Smart Fan Coil Thermostat with your LifeSmart Smart Station and other devices to make your life simple, and to let our monitor, control and even automate your home or office environment. LifeSmart Smart Fan Coil Thermostat can be perfectly integrated into the FCU central air conditioning smart control system, it upgrades water cooling, air-cooled central air conditioning, which applies to family, business or industry use.

You can now remote control your LifeSmart Smart Fan Coil Thermostat on LifeSmart App, as well as schedule to turn ON/OFF, voice control, trigger other smart devices and more.

SPECIFICATIONS

MODE	Cooling/Heating/Ventilating
OPERATING VOLTAGE	AC 230V 50/60 Hz
MAXIMUM LOAD	3A
POWER CONSUMPTION	1W
TEMPERATURE RANGE SETTING	16~32°C
DISPLAY	Set-Temperature and Monitored Temperature both shown
TEMPERATURE SENSOR	Thermistor B=3380 10k@25°C
SHELL MATERIALS	Fire-Retardant PC
CONNECTION METHOD	Crimp Terminal
SECTIONAL AREA OF CONDUCTOR	0.5~2.0 mm ²
The temperature measurement is accurate to 0.1°C. It is also featured with temperature correction.	

LifeSmart SMART FAN COIL THERMOSTAT



从左到右:

- MODE
- FAN SPEED
- ON/OFF
- DOWN
- UP

OPERATIONS

1. “开关图标” to turn ON/OFF. Room temperature and ‘OFF’ will be shown when it’s turned off.
2. “上图标” and “下图标” to set up temperature and adjust other settings.
3. Press “风速图标” to set fan speed. “风速黑图标” indicates speed volumes which are LOW/MID/HIGH/AUTO. When under AUTO mode, the thermostat adjusts the fan speed automatically according to the calculation of temperatures.
4. Press “切换图标” to switch between Cooling and Heating mode. “制热图标” stands for Heating. “制冷图标” stands for Cooling.

WIRE OPERATIONS

Please install wires in strict accordance with the wiring layout on the back of the power box. Or we won't be responsible for the damage of the product.

图标从7到1分别为：

Valve Open

Valve Close

High

Mid

Low

Live Wire

Neutral Wire

App Installation

Get LifeSmart by scanning the QR code below:

1. Power on, press and hold “向上图标” for at least 5 seconds until the indicate light flashes, then click “Start Pairing”.
2. Smart Thermostat starts pairing. When it's connected, click “Confirm” to finish pairing.
3. If pairing is failed, please repeat the steps above until pairing is successful.

PRODUCT INSTALLATION

HOW TO INSTALL

1. Separate the outer frame and the thermostat;
2. Separate the power box bottom with iron stand and the panel with the display screen;
3. Install wires in strict accordance with the wiring layout on the back of the power box;
4. Fix the iron stand of the power box to embedded bottom case with screws;
5. Put the outer frame on and place the panel into the power box.

HOW TO UNINSTALL

1. Remove the outer frame and the panel;
2. Remove all the screws and pull out the thermostat.

Smart Fan Coil Thermostat is a high precision electronic apparatus. Do not apply too much pressure on the LCD screen. Do not scratch or bump the device. Do not drop the device into slurry or deform the shell.

FEATURES

1. If “图标” is lit, the actuator or valve is active.
2. Press and hold “图标+图标“ for 2 seconds, the key pads will be locked and “图标” will be shown on screen. To unlock it, press and hold “图标+图标” for 2 seconds again.
3. Press any key to trigger the screen backlight, which will be turned off in 10 seconds automatically.

SYSTEM MENU SETTINGS

Press “开机图标” when it’s turned off and press “风速图标” immediately after to enter advanced settings. Press ”图标“ and “图标” to initiate selecting submenu, and press “图标” and “图标” to adjust the value. Press “图标” to save and quit system menu settings.

ON DISPLAY	SETTINGS	RANGE	FACTORY DEFAULT
Fn	Fan Control	OFF: Valve and fan off ON: Valve off, fan in slow	ON
bL	Backlight	OFF: turns off in 5 sec after no operation ON: always lit	OFF
Sat	State after Power Cut	OFF: power off ON: same state before power cut	ON

SYSTEM MENU SETTINGS

ON DISPLAY	SETTINGS	RANGE	FACTORY DEFAULT
CAL	Temperatur Correction	-5°C-5 °C	-2.5°C
dt0	Sensor Hysteresis	0.2°C-5°C	1.0°C
Add	Network Address Setting	1-255	001
deF	Factory Default Setting	Restore	ON

WARRANTY DESCRIPTION

Thank you for purchasing this LifeSmart product. In order to protect your right, please read the following content carefully: The warranty period of our company's products is one year from the date of purchase or longer if local laws impose a longer minimum term, in which case the minimum term is the warranty period. During the warranty period, any faults caused by the product itself for quality problems that arise under normal usage, LifeSmart will provide a free replacement.

ATTENTION

The following conditions are not covered by the warranty:

Product failure or damage caused by installation, use, and maintenance that is not in accordance with the product instructions;

Products beyond the warranty period;

Products that have the barcode tampered with or removed;

Devices that have been tampered with or customised outside of LifeSmart Terms of Service as on the LifeSmart APP and website;

User-Caused damage, such as inappropriate voltage input, high temperature, accidental spillage, physical damage, etc;

Product failure or damage caused by force majeure such as earthquakes, fires or floods;

Product failure or damage caused by other problems except the product itself.

IN YOUR PACKAGE

Panel with screen 1

Screws patch 1

Power Bottom Box 1

User's Guide 1

Please contact our customer service team before you send over for replacement through
400-886-1911

TECH SUPPORT

Email:

Telephone:

QQ:

Website

DECLARATION

LifeSmart is a trademark of Hangzhou LifeSmart Technology Co., Ltd. As for the trademarks, product logos and product names from other companies presented within this manual, they are possessed by their own right holders. Without our written permission, no entity or individual shall extract, copy or disseminate in part or the whole of the manual contents in any form. Due to product version upgrades or other reasons, content of this manual may change. Our company reserves the right to change the contents of this manual without any notice. This manual is used only for instructional purposes. We strive to provide accurate information in this manual, but we are not able to ensure that the content of this manual is current. Statements, information and advice in this manual do not constitute any expressed or implied assurance. Updated manuals are available on our website at www.ilifsmart.com or by contacting our Happiness Team.

Copyright © 2017 Hangzhou LifeSmart Technology Co., Ltd. All rights reserved.